

**DART**

DESIGN <i>[Signature]</i>	DRAWN BY <i>RF</i>	DART AEROSPACE USA, INC. BELLEVUE, WA	
CHECKED <i>[Signature]</i>	APPROVED <i>[Signature]</i>	DRAWING NO. DSI 9188	REV. A SHEET 1 OF 1
DATE 00.05.17		TITLE SADDLE KIT	SCALE NTS
A	00.05.17	NEW ISSUE	

## **DART SERVICE INSTRUCTION**

TO AMEND INSTALLATION DRAWING D206-642 REV. A-G

REF. US FAA STC: SA00475SE

CANADIAN STC: SH98-4

THE PURPOSE OF THIS SERVICE INSTRUCTION IS TO OUTLINE THE SADDLE KITS REQUIRED TO CHANGE FROM D2661/ D2662/ D2663/ D2664 SADDLES (D206-642 REV. A-F) TO D2932/ D2933/ D2938/ D2939 SADDLES (D206-642 REV. G). D206-642-311/ -411 REQUIRE DSI 9188-011 AND D206-642-312/-412 REQUIRE DSI 9188-012. INSTALL D2932/ D2932/ D2938/ D2939 SADDLES PER D206-642 REV. G

Qty -011	Qty -012	Part Number	Description
X		DSI 9188-011	SADDLE KIT
	X	DSI 9188-012	SADDLE KIT
16	16	D2652	BUSHING
1		D2932-1	SADDLE, FWD OUT, LH
	1	D2932-2	SADDLE, FWD OUT, RH
1		D2933-1	SADDLE, FWD IN, LH
	1	D2933-2	SADDLE, FWD IN, RH
2	2	D2934	SADDLE SPACER
2	2	D2935	SADDLE SPACER
1		D2938-1	SADDLE, AFT OUT, LH
	1	D2938-2	SADDLE, AFT OUT, RH
1		D2939-1	SADDLE, AFT IN, LH
	1	D2939-2	SADDLE, AFT IN, RH
8	8	AN3-41A	BOLT
12	12	AN4-6A	BOLT
4	4	AN5-10A	BOLT
8	8	AN5-11A	BOLT
4	4	AN5-12A	BOLT
4	4	AN5-13A	BOLT
8	8	AN960JD10	WASHER
24	24	AN960JD416	WASHER
8	8	AN960JD516	WASHER
8	8	MS21042-3	NUT (OR MS21042L3)
12	12	MS21042-4	NUT (OR MS21042L4)

Copyright © 2000 by DART AEROSPACE USA, INC.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.